

Batting comparison chart

What batting shall I pick for my quilt?



Compare some of the most popular batting products that are available to help you choose one that will make your next quilt look and feel **great**.

	Construction	Loft	Shrinkage (cold vs. warm wash)	Prewash	Quilting Distance
100% COTTON					
Quilters Dream Batting					
Dream Cotton Request®	Needle Punched	Low Loft	1% - 3%	No	8"
Dream Cotton Select®	Needle Punched	Mid Loft	1% - 3%	No	8"
Dream Cotton Deluxe®	Needle Punched	Mid-High Loft	1% - 3%	No	8"
Dream Cotton Supreme®	Needle Punched	High Loft	1% - 3%	No	8"
Hobbs Bonded Fibers					
Heirloom® & Tuscany®	Needle Punched	1/8"	3% - 5%	No	4"
Heirloom Natural with Scrim®	Needle Punched w/ scrim binder	1/8"	3% - 5%	No	8"
Heirloom 100% Organic®	Organic	1/8"	3% - 5%	No	4"
Heirloom® & Tuscany® Bleached	Needle Punched	1/8"	3% - 5%	No	4"
The Warm Company					
Warm & Natural®	Needle Punched	<1/8"	3% - 5%	Soak	10"
Warm & White®	Needle Punched	<1/8"	<1%	Soak	10"
Warm 100®	100% Cotton Scrim	<1/8"	<3%	Soak	10"
Pellon Batting					
Nature's Touch® 100% Cotton	Needle Punched	1/16"	3% - 5%	Soak	4"
Nature's Touch® Bleached	Cotton w/ Scrim	1/16"	3% - 5%	Soak	8" - 10"

Batting comparison chart (continued)

	Construction	Loft	Shrinkage (cold vs. warm wash)	Prewash	Quilting Distance
BLENDED BATTING (% Cotton & % Polyester)					
Quilters Dream Batting					
Quilters Dream® 80/20	Needle Punched	Low Loft	<3%	No	8"
Quilters Dream Blend® 70/30	Needle Punched w/ Scrim	Low Loft	<1%	No	12"
Hobbs Bonded Fibers					
Heirloom® Premium 80/20	Resin Bonded & Needle Punched	1/8"+	3% - 5%	No	4"
Heirloom® 80/20 Black	Resin Bonded & Needle Punched	1/8"+	3% - 5%	No	4"
Heirloom® 80/20 Bleached	Resin Bonded & Needle Punched	1/8"+	3% - 5%	No	4"
The Warm Company					
Warm 80/20®	Needle Punched w/ Scrim	Low Loft	3%	No	10"
Pellon					
Pellon® 80/20 Natural Blend	Scrim Binder	1/16"	3% - 5%	Soak	8" - 10"
Pellon® 70/70 Dark Blend	Needle Punched w/ Scrim	Low Loft	3% - 5%	Soak	10"
Pellon® 50/50 Light Blend	Scrim Binder	Low Loft	2% - 3%	Soak	8" - 10"

Batting comparison chart (continued)

	Construction	Loft	Shrinkage (cold vs. warm wash)	Prewash	Quilting Distance
100% POLYESTER BATTING					
Quilters Dream Batting					
Quilters Dream® Black	Needle Punched	Mid Loft	0%	No	12"
Quilters Dream® Poly	Needle Punched	3 Loft Options	0%	No	12"
Quilters Dream® Puff	Thermally Bonded	1/3" - 1/2"	0%		10"
Hobbs Bonded Fibers					
Tuscany®	Resin Bonded Siliconized Poly	1/4"	0%	No	4"
Cloudloft®	Resin Bonded	12" - 5/8"	0%	No	4"
Poly-Down	Resin Bonded Siliconized Poly	1/4"	0%	No	4"
Thermore®	Resin Bonded Poly Patented	1/16"	0%	No	9"
The Warm Company					
Soft & Bright	Fibers				
	Needle Punched w/ Scrim	Mid Loft	0%	No	10"
Pellon					
Quilter's Touch® High Loft	Thermally Bonded	1/8"	2% - 3%	No	4"

Batting comparison chart (continued)

	Construction	Loft	Shrinkage (cold vs. warm wash)	Prewash	Quilting Distance
SPECIALTY BATTING					
Quilters Dream® Wool	Thermally Bonded	1/3"+	0% - 3%	No	8"
Hobbs Tuscany® 80 Cotton/20 Wool	Resin Bonded	1/8"+	3% - 5%	No	4"
Hobbs Heirloom® & Tuscany® Wool	Washed Wool & Resin Bonded	1/4" - 3/8"	3% - 5%	No	4"
Hobbs Tuscany® 90% Silk/10%Poly	Resin Bonded & Needle Punched	1/8"	3% - 5%	No	4"
Pellon® 50/50 Wool/Cotton	Needle Punched w/Scrim	Low-Mid Loft	3% - 5%	No	10"
Pellon® 50/50 Bamboo/Cotton	Needle Punched w/Scrim	1/16"	2% - 3%	Soak	8" - 10"
Quilters Dream® Orient	Needle Punched	Low-Mid Loft	0%-3%	No	8"